The BrewBelt™ Fermentation Heat Belt

Manufactured and tested in accordance with CSA 22.2 No. 64-M91 and UL 499 standards. Certified for use in both Canada and the U.S.A. © 2001 Winemakeri inc. PATENT PENDING

Instructions for Use:

The BrewBelt™ is an adjustable heating belt that wraps around a 7-7.5 U.S. gallon (27-30 L) plastic pail or a 6 U.S. gallon (23 L) single-stage plastic fermenter. It will maintain 6 U.S. gallons (23 L) of fermenting beverage (beer wort, wine must or SuperYeast™ X-Press at a constant brewing temperature, approximately 75-80 ºF (23-27 ºC) for a period of up to 8 days. Home brewing in cold or damp conditions often requires this additional heat source to maintain minimum fermentation temperatures. Affix the belt onto a plastic pail as per the above diagram.

1. Loosen the power cord. Slide the loosened belt over the top of the pail so the power cord is facing you.
2. Position the belt around the outside of the pail so the belt is approximately 1/3 down from the top of the pail.
3. Note: If using a single-stage plastic fermenter, affix the belt in this manner: position the belt around the outside of the fermenter so the belt lies flat in the recessed belt groove).
4. Loop the end of the power cord under and over the part of the cord that lies flat against the pail. Ensure the belt remains in this optimum heating position.
5. Plug in the power cord. It will begin to heat immediately.
6. DO NOT cover the belt with a blanket or any other covering. This may cause the belt to overheat.
7. DO NOT store flammable objects near the belt while in use.
8. DO NOT leave the belt plugged in for more than 8 consecutive days or until the S.G. (specific gravity) drops below 1.010, whichever comes first.
9. DO NOT use the belt if the room temperature rises above 75-80 ºF (23-27 ºC).
10. DO NOT attempt to affix the belt to a glass (e.g. carboy or demijohn), metal or wooden fermenter.

Warranty:

This product is conditionally guaranteed against defective materials and workmanship for 1 year from the date of purchase. Guarantee void if product is damaged, altered, tampered with or otherwise misused.

Updated 04/12/2021